



## Fence-Guard SteadyMax Pole Attachment



### SteadyMax Pole Fit Location

- 25' Pole within top 5-1/2'
- 20' Pole within top 5-1/2'
- 16' Pole anywhere
- 12' Pole anywhere

When monitoring a fence line, property line or perimeter areas, it is vitally important that the cameras be as steady as possible in order for the Camera Analytics to work efficiently without a lot of errors and false alarms.

The Fence-Guard Attachment was developed to help guard a High Security Facility. This attachment was designed to aim cameras down a fence line in both directions (or even at corners), and can also hold a PTZ Camera if needed. It was also designed to thwart someone from throwing a grapple and snagging it (hence – the downward angle and closed-off openings)

